


FIG. 1






FIG. 3

Serial No.: 10/816,705; Art Unit: 2623 Replacement Sheet

ROC919990202US2

Start Time	10:00 11:0	TV TV Event Ev #1	TV TV Ev #	TV TV Ev Ev #	TV TV Event Ev #
	00:6	TV Event #1	TV Event #2	TV Event #3	TV Event
	8: 00	TV Event #1	TV Event #2	TV Event #3	TV Event #5
Channel		500	501	502	503




FIG. 5

Replacement Sheet




FIG. 6




FIG. 7

ROC919990202US2 8/18 ___800 **801**-**Start** -802 ls Ring Detected Yes No on Telephone Line 803 ls DND Flag Yes Nο Set 804 806 **Answer Call** ls Number Yes No of Rings Exceeded 805 Play Greeting Indicating when Television Event Ends 807 **Answer Call** 808 **Play Greeting**

Fig. 8A Fig. 8B

FIG. 8A




FIG. 8B







FIG. 9

Replacement Sheet ROC919990202US2 11/18







FIG. 11

Replacement Sheet

ROC919990202US2






FIG. 12B




FIG. 12C




FIG. 12D

Replacement Sheet

ROC919990202US2




FIG. 12E

Replacement Sheet ROC919990202US2 18/18 1301-- 1300 Start 1302 Has 1303 Set_Top_Box Yes End Been Re-Enabled No 1304 Disable Set Top Box -1305 Display Dialog Box Requesting Password -1306 -1310 Did \ Has Calling Party Password Been No No Request TV Set Be Received Re-Enabled ? Yes Yes 1307 ls No **Password Correct** Yes 1308 Re-Enable Set Top Box

FIG. 13

1309

End